

INSTALLATION MAP

To Sheet / A la hoja de:

Panel Group:
Tilt/Inclinación:
Sheet ____ of ____

Customer:

Installer:

N S E W

	1	2	3	4	5	6	7	8	9
A									
B									
C									
D									
E									
F									
G									
H									
J									
K									
L									
M									

To Sheet :

Scan completed map and upload it to Enphase. Click “Add a New System” at <https://enphase.com/installers/apps>.

Gateway Serial Number Label

© 2025 Enphase Energy. All rights reserved. Enphase, the e and CC logos, IQ, and certain other marks listed at <https://enphase.com/trademark-usage-guidelines> are trademarks of Enphase Energy, Inc. in the U.S. and other countries. Data subject to change. 2025-08-28.

Enphase Support: <https://enphase.com/contact/support>

QUICK INSTALL GUIDE



Install the IQ8 Series Microinverter

To install IQ8 Series Microinverters, read and follow all warnings and instructions in this guide and in the *IQ8 Series Microinverter installation and operation manual* at <https://www.enphase.com/support> . Safety warnings are listed in this guide.

The Enphase microinverter models listed in this guide do not require grounding electrode conductors (GEC), equipment grounding conductors (EGC), or ground conductor (neutral). The microinverter has a Class II double-insulated rating, which includes ground fault protection (GFP). To support GFP, use only PV modules equipped with DC cables labeled PV Wire or PV Cable.

IMPORTANT: IQ8 Series Microinverters require the IQ Cable. An IQ Gateway is required to monitor the performance of the IQ Microinverters. The IQ accessories work only with IQ8 Series Microinverters.

- ✓ **NOTE:** 1) After you log in to your Enphase Account from the Enphase Installer App, scan the microinverter serial numbers (1D bar code) and connect to the IQ Gateway to track the system installation progress.
2) The installer must check the manufacturing date of the products to ensure that the installation date is within one year of the manufacturing date of the products. Contact the local distributor to validate the date code.

PREPARATION

- A) Download the Enphase Installer App and open it to log in to your Enphase Account. With this app, scan microinverter serial numbers (1D bar code) and connect to the IQ Gateway to track system installation progress. To download, go to <https://enphase.com/installers/apps> or scan the QR code.



- B) Refer to the following table and check PV module electrical compatibility at <https://enphase.com/installers/microinverters/calculator>

Model	DC connector	Typical PV module* cell count
IQ8-60-2-US	MC-4 locking type	Pair with 60-cell/120-half-cell modules
IQ8PLUS-72-2-US IQ8M-72-2-US IQ8A-72-2-US	MC-4 locking type	Pair with 60-cell/120-half-cell, 66-cell, or 72 cell/144-half-cell
IQ8H-240-72-2-US IQ8H-208-72-2-US	MC-4 locking type	Pair with 60-cell/120-half-cell, 66-cell, or 72-cell/144-half-cell

* IQ8 Series Microinverters are compatible with bifacial PV modules if the temperature-adjusted electrical parameters (maximum power, voltage, and current) of the modules, considering the front side electrical parameters (i.e., 0% back side gain), are within the allowable microinverter input parameters range.

- C) In addition to the Enphase microinverters, PV modules, and racking, you will need these:
- IQ Gateway (model ENV-IQ-AM1-240) communications gateway or IQ Combiner (check <https://enphase.com/> for models): Required to monitor solar production.
 - Tie wraps or cable clips (Q-CLIP-100).
 - IQ Sealing Caps (Q-SEAL-10): For any unused connectors on the IQ Cable.
 - IQ Terminator (Q-TERM-10): One needed at the end of each AC cable segment.
 - IQ Disconnect Tool (Q-DISC-10)
 - IQ Cable:

Cable model	Connector spacing*	PV module orientation	Connectors per box
Q-12-10-240	1.3 m	Portrait (all)	240
Q-12-17-240	2.0 m	Landscape (60-cell and 66-cell)	240
Q-12-20-200	2.3 m	Landscape (72-cell)	200

*Allows for 30 cm of cable slack

- D) Check that you have the following items:
- AC junction box.

- Tools: screwdrivers, wire cutter, voltmeter, torque wrench, sockets, and wrenches for mounting hardware.

- E) Protect your system with lightning and/or surge suppression devices. It is also important to have insurance that protects against lightning and electrical surges.

- F) Check compatibility when expanding an IQ7 system with IQ8 Series Microinverters:


- IQ8 Series Microinverters can be added to existing IQ7 systems on the same IQ Gateway/IQ Combiner only in the following configurations: (i) Solar Only or (ii) Solar Plus Battery (IQ Battery 3/10 or IQ Battery 3T/10T or IQ Battery 5P) grid-tied or with backup with IQ System Controller 3/3G/3M and IQ Meter Collar.
- The IQ7 Series Microinverters cannot be added to a site with the existing IQ8 Series Microinverters on the same gateway.
- A mixed system of IQ7 and IQ8 will not support the IQ8-specific sunlight jump-start feature.
- The rated continuous power output of the IQ7 Microinverter and IQ8 Microinverter arrays must not exceed 150% of the IQ Battery’s rated power output. If the microinverter array exceeds this ratio, PV shedding must be implemented to shed excess PV when the system transitions to the off-grid mode.

- G) Plan your AC branch circuits to meet the following limits for the maximum number of microinverters per branch when protected with a 20 A overcurrent protection device (OCPD).

Maximum* IQ8 Series Microinverters per AC branch circuit (single-phase)					
IQ8 (240 V)	IQ8+ (240 V)	IQ8A (240 V)	IQ8H (240 V)	IQ8H (208 V)	IQ8M (240 V)
16	13	11	10	9	11

* Limits may vary. Refer to local requirements to define the number of microinverters per branch in your area.

NOTE: For a mixed system containing both IQ7 and IQ8 Microinverters on the same branch, ensure that the total maximum continuous output current of all microinverters on the branch does not exceed 16 A.



H) Size the AC wire gauge to account for the voltage rise. Select the correct wire size based on the distance from the beginning of the IQ Cable to the breaker in the load center. Design for a voltage rise of less than 2% for these sections. Refer to the *Voltage Rise technical brief* at <https://enphase.com/contact/support> for more information.

Best practice: Center-feed the branch circuit to minimize voltage rise in a fully populated branch.

INSTALLATION

1 Position the IQ Cable

- Plan each cable segment to allow connectors on the IQ Cable to align with each PV module. Allow extra length for slack, cable turns, and any obstructions.
- Mark the approximate centers of each PV module on the PV racking.
- Lay out the cabling along the installed racking for the AC branch circuit.
- Cut each segment of cable to meet your planned needs.



WARNING: When transitioning between rows, secure the cable to the rail to prevent cable or connector damage. Do not count on the connector to withstand tension.

2 Position the junction box

- Verify that the AC voltage at the site is within range:

Service type and voltage: L1-L2	
240 V single-phase	211 to 264 VAC
208 V single-phase	183 to 229 VAC

- Install a junction box at a suitable location on the rack.
- Provide an AC connection from the junction box back to the electricity network connection using equipment and practices as required by local jurisdictions.

3 Mount the Microinverters

- Mount the microinverter horizontally, bracket side up, or vertically. Always place it under the PV module, protected from direct exposure to rain, sun, and other harmful weather events. Allow a minimum of 1.9 cm (3/4") between the roof and the microinverter. Also, allow 1.3 cm (1/2") between the back of the PV module and the top of the microinverter.


For vertical mount, also maintain >30 cm (12") clearance from the edges of the PV module to protect the microinverter from direct exposure to rain, UV, and other harmful weather events.




WARNING: Install the microinverter under the PV module to avoid direct exposure to rain, UV, and other harmful weather events. Do not mount the microinverter upside down.

- Torque the mounting fasteners (1/4" or 5/16") as follows. Do not over-torque.
 - 6 mm (1/4") mounting hardware: 5 N m (45 to 50 in-lb)
 - 8 mm (5/16") mounting hardware: 9 N m (80 to 85 in-lb)
- When using UL 2703 mounting hardware, use the manufacturer's recommended torque value

Horizontal mount:




Vertical mount:



4 Creat an installation map

Create a paper installation map to record the microinverter serial number and position in the array.


- Peel the removable serial number label from each microinverter and affix it to the respective location on the paper installation map.
- Peel the label from the IQ Gateway and affix it to the installation map.
- Always keep a copy of the installation map for your records.



Affix serial number labels

5 Manage the cabling


- Use cable clips or tie wraps to attach the cable to the racking. The cable must be supported at least every 1.8 m (6 feet).
- Dress any excess cabling in loops so that it does not contact the roof. Do not form loops smaller than 12 cm (4.75") in diameter.



Cable clip

6 Connect the microinverters

- Connect the microinverter. Listen for a click as the connectors engage.
- Cover any unused connectors on the AC cable with the IQ Sealing Caps. Listen for a click as the sealing caps engage.




WARNING: Install sealing caps on all unused AC connectors as these connectors become live when the system is energized. Sealing caps are required for protection against moisture ingress.

To remove a sealing cap or AC connector, you must use an IQ Disconnect Tool.

7 Terminate the unused end of the cable

- Remove 13 mm (1/2") of the cable sheath from the conductors. Use the terminator loop to measure.


Terminator body



- Slide the hex nut onto the cable.

- Insert the cable into the terminator body so that each of the two wires lands on opposite sides of the internal separator. There is a grommet inside the terminator body that should remain in place.

- Insert a screwdriver into the slot on the top of the terminator to hold it in place, and torque the nut to 7 N m.



Internal view

- Hold the terminator body stationary with the screwdriver and turn only the hex nut to prevent the conductors from twisting out of the separator.

- Attach the terminated cable end to the PV racking with a cable clip or tie wrap so that the cable and terminator do not touch the roof.



WARNING: The terminator can not be re-used. If you unscrew the nut, you must discard the terminator.

8 Complete Installation of the junction box

- Connect the IQ Cable to the junction box.
- The IQ Cable uses the following wiring color code:


Wire colors
Black – L1
Red – L2

9 Connect the PV modules



DANGER! Electric shock hazard. The DC conductors of this PV system are ungrounded and may be energized.

- If required, attach the Enphase DC bulkhead adapters to the microinverters. Make sure they are fully seated. Do not reverse the adapter connections.
- Connect the DC leads of each PV module to the DC input connectors or adapters of the microinverter.
- Check the LED on the connector side of the microinverter. The LED flashes six times when DC power is applied.
- Mount the PV modules above the microinverters.



10 Energize the System

- Turn ON the AC disconnect or circuit breaker for the branch circuit.
- Turn ON the main utility-grid AC circuit breaker. Your system will start producing power after a five-minute wait time.
- Check the LED on the connector side of the microinverter:

LED	Indicates
Flashing green	Normal operation. The AC grid function is normal, and there is communication with the IQ Gateway.
Flashing orange	The AC grid is normal, but there is no communication with the IQ Gateway.
Flashing red	The AC grid is either not present or not within specification.
Solid red	There is an active DC Resistance Low, Power Off condition. To reset, refer to the <i>IQ Gateway installation and operation manual</i> at: https://www.enphase.com/support .

ACTIVATE MONITORING AND CONTROLS

After you have installed the microinverters, follow the procedures in the IQ Gateway quick install guide to activate system monitoring, set up grid management functions, and complete the installation.

- Connecting the IQ Gateway
- Detecting devices
- Connecting to Enphase Installer Platform
- Registering the system
- Building the virtual array

Enphase Connector rating

Enphase Connectors on the cable assemblies in the following table have a maximum current of 20 A, a maximum OCPD of 20 A, and maximum ambient temperature of -40°C to 79°C (-40°F to 174.2°F) and are rated for disconnection under load.

Part number	Model	Maximum voltage
840-00387	Q-12-10-240	250 VAC
840-00388	Q-12-17-240	250 VAC
840-00389	Q-12-20-200	250 VAC
840-00385	Q-DCC-2	100 VDC

Revision history

Revision	Date	Description
140-00195-04	August 2025	- Added information on backward compatibility with IQ8/IQ7 Series Microinverters. - Updated IQ8 Microinverter compatibility with existing IQ7 systems.
Previous releases.		

PV Rapid Shutdown Equipment (PVRSE)

This product is UL Listed as PV Rapid Shut Down Equipment and conforms with NEC-2014 and NEC-2017 sections 690.12 and C22.1-2015 Rule 64-218 Rapid Shutdown of PV Systems, for AC and DC conductors, when installed according to the following requirements:

- Microinverters and all DC connections must be installed inside the array boundary. Enphase further requires that the microinverters and DC connections be installed under the PV module to avoid direct exposure to rain, UV, and other harmful weather events.
- The array boundary is defined as 305 mm (1 ft.) from the array in all directions, or 1 m (3 ft.) from the point of entry inside a building.

This rapid shutdown system must be provided with an initiating device and (or with) status indicator, which must be installed in a location accessible to first responders, or be connected to an automatic system that initiates rapid shutdown upon the activation of a system disconnect or activation of another type of emergency system. The initiator shall be listed and identified as a disconnecting means that plainly indicates whether it is in the OFF or ON position. Examples are:

- Service disconnecting means
- PV system disconnecting means
- Readily accessible switch or circuit breaker

The handle position of a switch or circuit breaker is suitable for use as an indicator. Refer to NEC or CSA C22.1-2015 for more information.

Additionally, in a prominent location near the initiator device, a placard or label must be provided with a permanent marking including the following wording: **PHOTOVOLTAGIC SYSTEM EQUIPPED WITH RAPID SHUTDOWN**. The term PHOTOVOLTAGIC may be replaced with PV.

The placard, label, or directory shall be reflective, with all letters capitalized and having a minimum height of 9.5 mm (3/4") in white on red background.

SAFETY

IMPORTANT SAFETY INSTRUCTIONS

SAVE THIS INFORMATION. This guide contains important instructions to follow during installation of the IQ8, IQ8+, IQ8A, IQ8H, and IQ8M Microinverters.

	WARNING: Hot surface.
	WARNING: Refer to safety instructions.
	DANGER: Risk of electric shock.
	Refer to manual
	Double Insulated

Safety symbols

	DANGER: Indicates a hazardous situation, which, if not avoided, will result in death or serious injury.
	WARNING: Indicates a situation where failure to follow instructions may be a safety hazard or cause equipment malfunction. Use extreme caution and follow instructions carefully.
	WARNING: Indicates a situation where failure to follow instructions may result in burn injury.
	NOTE: Indicates information particularly important for optimal system operation.

General safety

	DANGER: Risk of electric shock. Do not use Enphase equipment in a manner not specified by the manufacturer. Doing so may cause death or injury to persons or damage to equipment.
	DANGER: Risk of electric shock. Be aware that the installation of this equipment includes the risk of electric shock.
	DANGER: Risk of electric shock. The DC conductors of this photovoltaic system are ungrounded and may be energized.
	DANGER: Risk of electric shock. Always de-energize the AC branch circuit before servicing. Never disconnect the DC or AC connectors under load.
	DANGER: Risk of electric shock. Risk of fire. Only use electrical system components approved for wet locations.
	DANGER: Risk of electric shock. Risk of fire. Only qualified personnel should troubleshoot, install, or replace Enphase microinverters or the IQ Cable and accessories.

	DANGER: Risk of electric shock. Risk of fire. Ensure that all AC and DC wiring is correct and that none of the AC or DC wires are pinched or damaged. Ensure that all AC junction boxes are properly closed.
	DANGER: Risk of electric shock. Risk of fire. Do not exceed the maximum number of microinverters in an AC branch circuit as listed in this guide. You must protect each microinverter AC branch circuit with a 20 A maximum breaker or fuse, as appropriate.
	DANGER: Risk of electric shock. Risk of fire. Only qualified personnel may connect the Enphase microinverter to the utility grid.
	WARNING: Risk of equipment damage. Enphase male and female connectors must only be mated with the matching male/female connector.
	WARNING: Before installing or using the Enphase microinverter, read all instructions and cautionary markings in the technical description, on the Enphase microinverter system, and on the photovoltaic (PV) equipment.
	WARNING: Do not connect Enphase microinverters to the grid or energize the AC circuit(s) until you have completed all of the installation procedures and have received prior approval from the electrical utility company.
	WARNING: When the PV array is exposed to light, DC voltage is supplied to the PCE.
	NOTE: To ensure optimal reliability and to meet warranty requirements, install the Enphase microinverters and IQ Cable according to the instructions in this guide.
	NOTE: Provide support for the IQ Cable at least every 1.8 m (6 feet).
	NOTE: Perform all electrical installations in accordance with all applicable local electrical codes, such as the Canadian Electrical Code, Part 1 and NFPA 70 (NEC).
	NOTE: Protection against lightning and resulting voltage surge must be in accordance with local standards.

IQ Cable safety	
	DANGER: Risk of electric shock. Do not install the IQ Terminator while power is connected.
	DANGER: Risk of electric shock. Risk of fire. When stripping the sheath from the IQ Cable, make sure the conductors are not damaged. If the exposed wires are damaged, the system may not function properly.
	DANGER: Risk of electric shock. Risk of fire. Do not leave AC connectors on the IQ Cable uncovered for an extended period. You must cover any unused connector with a sealing cap.
	DANGER: Risk of electric shock. Risk of fire. Make sure protective sealing caps have been installed on all unused AC connectors. Unused AC connectors are live when the system is energized.
	WARNING: Use the terminator only once. If you open the terminator following installation, the latching mechanism is destroyed. Do not reuse the terminator. If the latching mechanism is defective, do not use the terminator. Do not circumvent or manipulate the latching mechanism.
	WARNING: When installing the IQ Cable, secure any loose cable to minimize tripping hazard
	NOTE: When looping the IQ Cable, do not form loops smaller than 12 cm (4.75") in diameter.
	NOTE: If you need to remove a sealing cap, you must use the IQ Disconnect tool.
	NOTE: When installing the IQ Cable and accessories, adhere to the following: - Do not expose the terminator or cable connections to directed, pressurized liquid (water jets, etc.). - Do not expose the terminator or cable connections to continuous immersion. - Do not expose the terminator or cable connections to continuous tension (e.g., tension due to pulling or bending the cable near the connection). - Use only the connectors and cables provided. - Do not allow contamination or debris in the connectors. - Use the terminator and cable connections only when all parts are present and intact. - Do not install or use in potentially explosive environments. - Do not allow the terminator to come into contact with open flame. - Fit the terminator using only the prescribed tools and in the prescribed manner. - Use the terminator to seal the conductor end of the Enphase IQ Cable; no other method is allowed.

DC cable safety

	NOTE: Ensure proper routing of PV Module DC cable using the clips to prevent the leads from resting on the roof. Do not wrap extra DC Cable around microinverter.
	NOTE: Avoid direct exposure to sunlight.
	NOTE: Avoid sharp edges on racking.
	NOTE: Avoid cable touching rough surfaces or moving parts within racking system.
	NOTE: Avoid overly tight bending radii. Minimum bend radii for the DC cable is eight times the outer diameter or R55mm.
	NOTE: Avoid overly tightly sized cable clips for routing.

Enphase Support: <https://enphase.com/contact/support>